JUHS02-K (white porcelain handle)

JUHS03-K (black porcelain handle-MTO)

23%"

► To ensure this product is installed properly, you

➤ The owner/user of this product must keep this

➤ Be sure your installation conforms to local codes.

 \blacktriangleright A wall value or diverter value (sold separately) controls on/off/volume and must be installed for

➤ This product must be installed by a professional

► Refer to the specification and assembly drawings attached. This product is sold partially assembled but shown fully disassembled for illustrative and

► Inspect this product to assure you have all parts

► Use only a strap wrench or protected/smooth-jaw

must read and follow these guidelines.

information for future reference.

proper operation of this product.

2 ¼ "Ø

JUHS01-K (metal handle)

IMPORTANT

contractor.

service purposes only.

Associate for current specifications.

required for proper installation.

wrench on any finished surface

Installation Guidelines



- I. Install a wall valve or diverter valve(sold separately) at the desired location.
- 2. Finish the rough in by installing a well supported $\frac{1}{2}$ " female IPS elbow.
- 3. Determine the ideal location of the bar assembly based on the clients preference and install wood blocking or position over a stud to properly secure the bar.

BAR AND ELBOW INSTALLATION:

- 4. The inlet elbow (2) is $\frac{1}{2}$ " female IPS; install the elbow using a nipple of appropriate length.
- 5. Drill holes at the proper spread of $23\frac{5}{8}$ " to accommodate the screw anchors (7c) and bar mounting screws (7a).
- 6. Remove the cap (7) from each bar end (7b), thread the screw (7a) into the wall then reinstall the cap.
- 7. Install the hand shower onto the conical end (4b) of the hose
- 9. To adjust the height of the hook, loosen the knob (5).

If further assistance is required, please contact Product Support at 1-800-927-2120 (8am-7pm EST).

These guidelines have been prepared for the professional contractor to aid in the installation of: JULIA HANDSHOWER ON BAR (JUHS01-K, JUHS02-K, JUHS03-K) All dimensions are based on original specification and are subject to change and variation. Please consult your Design

WATERWORKS

- 8. To adjust the angle of the hook, loosen the nut (5h).

Installation Guidelines

